



PL

Vertical level indicator

- ▶ Used for checking fluid level in large tanks.
- ▶ Complete with seals, screws and anchor nuts.
- ▶ Easy to assemble, it gives a tolerance of 0,5 mm along the interhole axis, maintaining a perfect seal.
- ▶ Avoid contact with **alcohol, toluol and glycol**.

[PRINTING NOTES](#)
[PRINT](#)

TYPE	CODE	L	r	v	c	i	f	h	a	b
PL1	1VPLV10A	109	34	37	16,5	76	M 10	21,5	11	29
PL2	1VPLV20A	160	34	88	16,5	127	M 12	21,5	16	29
PL3	1VPLV30A	287	34	215	16,5	254	M 12	21,5	16	29



the safety of metal